## HICYDOCK":

## Installing the device




Fig.2







Fig.4a for CKDF

Fig.4b for CPF

- 1. Unlock the front door by inserting the key provided, turning the key counterclockwise. Pull to open the front door. (Fig.1 - Fig.2 CKDF only)
- 2. Use the miniature key and insert into the key hole to eject handle. (Fig.3)

Fig.3

3. Removing the HDD carrier away from the body. (Fig.4a) (Fig.4b)







Fig.7a for CKDF



Fig.7b for CPF




Fig.8a for CKDF



Fig.8a for CPF

6. Inserting the carrier along with HDD into the body. 7. Keep the handle angled from the carrier, then slide the Align the two sides of carrier with the anti-shock rails carrier along the anti-shock rails and into the body until located at the left and right sides inside the body. (Fig.7a) fully inserted. (Fig.8a) (Fig.8b)








Fig.10a for CKDF



Fig.10b for CPF

8. Push the handle towards the carrier until it click to completely secure the position of carrier. (Fig.9)

Flg.9

9. Close the front door and insert the key into the lock hold to lock. Turning the key clockwise to complete HDD installation. (Fig.10a) (Fig.10b)

- (1) HDD failure will Indicate Red only when signal is inputted by controller. ( please refer to HDD -Fail signal )
- (2) Please terminate the last connector using a terminator
- (3) The above testing results were obtained under the surrounding temp at
- (4) Any unrelated changes on the technical specification are subject to change without prior notice.
- (5) We will not be liable responsible for any software · hardware · or other data stored within, or interfacing with our product which resulted to being damaged / dysfunctional. Cremax will only be responsible to repair / service its own product.
- (6) For any further inquiries about product application or more related product information, please linked to: www.icydock.com.